whitefurze

SELF-WATERING BOSTON PLANTER



Includes insert tray – forms reservoir for a balanced water supply

For use with Boston Squcer

Planting and watering instructions

The Boston Self-Watering system keeps plants fresh and healthy by providing a balanced water supply for optimum growth.

Set-up guide

- Ensure the insert tray is clipped into the base of the planter, this will form the water reservoir for your plant
 - Place the planter on an even surface
 - Set your plant in the pot and fill with soil or compost
- Water the plant slowly from above through the soil. The draining spout in the base of the pot will allow excess water to drain this means the reservoir is full and you should stop watering.

Warning: when used indoors, planter must be used with saucer.

How it works

The water reservoir in the base of the pot provides the plant with a balanced water supply for optimum growth, helping your plant to thrive even when you are unable to water it regularly.

How often should I water?

During this early period, continue to water the plant from above through the soil. The capillary action of the compost will draw water from the moist area around the reservoir which will in turn provide moisture to the rest of the pot.

After the plant has become established the roots will draw water from the reservoir and moist area without your assistance.

Following this early period, watering intervals will depend on planter size and location. The larger the plant and the warmer the location, the shorter the watering intervals.